

# 2G Monitoring Software Manual V1.0

2018-03-19

## 1.2 From Ginlong Platform 2.0 Web



Input Platform 1.0 account username & password.

	Platform 2.0 login gu
Please enter	your username and password for
Platform:	Ginlong(ginlongmonitoring
Username:	ginlongazs
Password:	•••••

Platform 2.0 Login Guide Notice: The system checks the username and password.

Platform 2.0 Website: <u>http://m.ginlong.com</u>

After 1.0 users account information is verified, system will show 2.0 account information. If user had not logged in Platform 2.0 before, the system will register a new account on Platform 2.0 in the form of uid@Ginlong.com. If the user has logged in Platform 2.0 before, it will directly display user 2.0 account information. Users can click "login" to login directly with Platform 2.0 account information.

#### Notice:

Login button: the system automatically recognizes the account type and guides users to corresponding versions, i.e. PV owners login to m.ginlong.com (home version) and PV merchants (installers/distributors) login to m.ginlong.com (professional version). Click to download more info button: click this button to download this document.



account information will show.

Platform 2.0 Login Guide Notice: Help guide for users with problem.

×

# PART 02 Ginlong Professional Version

# 1. Create Plants and WiFi Configuration

Ginlong Professional Ver. APP support creating plants and WiFi Configuration Ginlong Professional Ver. Web support adding plants only

Create Plants

•WiFi Configuration

### 2.1 Create Plants

#### 2.1.1 Create a new Plant

#### A. Ginlong Professional Ver. APP

#### 1. Start to create a new plant

Click "add" at the bottom main menu and click "plant". Or, click the plant icon, enter the list of power stations, and then click "+" to start to create a new plant .

#### P 78% 양<sup>0</sup> 47% 🔲 < Plant 3 0 Total Gaga的电站 江苏省无锡市新吴区312国 5.00m Current Power Daily Generation 2018-03-31 20:54:37 Scan Device ✓ 包宏伟的电站 中国江苏省无锡市滨湖区 5.00m Current Power Daily Generation Plant Device WiFi 2017-11-02 17:26:56 〇 电表 江苏省无锡市新吴区萎湖. 5.00m Current Power Daily Generation 2018-03-23 10:31:00

#### 2. Scan the code

APP only supports the scanning of the bar code/QR code of dataloggers. If there is no datalogger, you can click the "no device" and jump to the next step: input plant information.

#### 3. input plant information

The system automatically locates the location of the station via the mobile phone GPS. If you are not in the site, you can also click "map" to select on the map.



# 4. Enter the name of the plant and the owner's contact number.



#### 5. Associated with the owner

When the plant is completed, the system will prompt "Do you need to associate the plant owner?".



- The creator is the owner: select this option to indicate that the merchant who created the plant is the owner of the plant.
- Associate with owner's ID (recommended): the owner can find the ID number on the upper part of the "my" interface in APP.
- Create an account for the owner: you can also create an account of Ginlong home version for the owner, which can only be used on the Ginlong home app. Support mobile number and mailbox (not verified), and default password is 123456.
- No. ID number: you can enter the owner's name but not the details of the Ginlong home app account.

#### **B. Ginlong Professional Web**

## 1. Click "New plant" in the Plant Centre.

CR	Plant Center Device Center	Alert Center Report Center Tio	ket Center		Search plant, device		Q 🖉	🥳 ginlong 🗸
«	Plant Center > Project Management > Pr	roject Overview > Status ~ Region ~	Project Type V Capacity V Name : Nor	ne 🗸 Clear			Set the visible fie	ld New Plant
▼ Project Management	Real-time Timeline							
Project Overview	Operating Status	Updated by : 2018-04-03 10:03 🛛 🕄	Generation Overview	Up	odated by : 2018-04-03 10:03 🛛 🕄	Within an Hour Alert	Updated by : 2018-04-0	13 10:03 📿 >
🖌 Project Diagrams	56861 Total Plants	Normal Offline 34902 20375 Alert Building 1195 389	Larrest Power 3321,350Vp Stre Capacity	Vally Generation Mo 2.486Wh 23 Unrula Generation Tot 4284.356Wh 30	onthly Generation 39.67 gwh tal Generation 008.47 gwh	1801 Alerts 2 1002 表文总域時代-李福特 Invent	Warnings Fau O 18 er-NO-Gridt元电洞Alert Code	ilt 801 : 1015H
	Map Map Satella usess Units Sates	triate 10070-care Faret Seat <sup>o</sup> May Atlantic	72 Karabitar 615 1196 "Core Sank tare	North Pacific	Cristic 29 368 Utilet States	2 North Atlantic	Polasd entary Ucane Kati Haly Tartey Afd	ahatan Ma

2. Input plant information



Please Edit if Current Address Inaccurate

Name Project Type

On-grid Type

Address: ChinaJiangsu ShengWuxi ShiBinhu QuLing Hu Da Dao232@-240@ : Long8tude 120\*21'40\* Latitude 31\*30'24\* Ling Hu Da Dao Nearby

Capacity (kWp)	5.00			
Project Timezone	(UTC+08.00) Beijing.Chongqing.Hong Kong.Urumqi 🗸 🗸			
Azimuth (*)	180*			
Angle of Tilt (*)	26'			
Currency	CNY v			
Benchmark Price(CNV/kWh)	۵.75			
Province Generation FIT(CNV/kWh)	0	Period(yr)	0	~
City Generation FIT(CNV/kWh)	0	Period(yr)	0	~
County Generation FIT(CNV/kWh)	0	Period(yr)	0	~
Building Cost(CNV)	37500.00			
Building FIT(CNV)	1000			
Loan Proportion (%)	•			
Annual Loan Rate (%)	0	Period(yr) 0	~	
Refund Method	Fixed-basis Mortgage OFixed-payment Mortgage			
Contact Number				
	Next			

Confirm Pla Description	t.	Confirm Correlation
Inter Asso User	al Search for user or click to se	elect
Crea	or ginlong	hunar2

A. Interrelated users: connect the plant to other users within the company.

n Plant iption		Confirm (
Internal Association	Search for user or click to select	
User	The following is all the business Account, please click to select	
Creator	g Vivintsolar	
Owner	大海科源 Demo演示电站	
	Select All Selected : 0/1000	

# B. Related owner: the plant is bound to the owner's account (Ginlong home version account)

Confirm Plant Description		Confirm Co Info
Internal Association	Search for user or click to select	
C	eielene	
Creator	giniong	
Owner	I Am Owner Y What Is Owner?	
Owner	I Am Owner What Is Owner?	
Owner	I Am Owner V What Is Owner? I Am Owner Correlate Owner's PV Monitor ID Create a PV Monitor ID for Owner	

- The creator is the owner: select this option to indicate that the merchant who created the plant is the owner of the plant.
- Associate with owner's ID (recommended) : the owner can find the ID number on the upper part of the "my" interface in APP.
- Create an account for the owner: you can also create an account of Ginlong home version for the owner, which can only be used on the Ginlong home app. Support mobile number and mailbox (not verified), and default password is 123456.
- No. ID number: you can enter the owner's name but not the details of the Ginlong home app account.

#### 3. Association owners and members of internal organizations

#### 4. Add a device

Enter the Plant Details - Device, the system will pop up the input box, fill in the device SN number to complete the add equipment.

- Ginlong Professional Web support to add datalogger and inverter.
- Select inverter/datalogger in device type.
- Supports batch import of devices in Excel format. The import format is as follows, and all SN columns are entered in sequence.

	Add Ne	w Device		
Device Type	Data Logger	~	0	
Brand	SOLARMAN	~		
SN Number			Add	Import
SN Numb	er	Action		
	( Not A			

	D21		Q	fx		
	1	A			В	}
1	1425010	770				
2	1425010	771				
3	1425010	772				
4	1425010	773				
5	1425010	774				
6	1425010	775				
7	1425010	776				
8	1425010	777				
9	1425010	778				
0	1425010	770				

# 2.2 WiFi Configuration

GPRS datalogger can be automatically connected to the Internet, but if it is WiFi datalogger, we need make datalogger configured to the router connected to the Internet. Ginlong Pro ver. App will support WiFi datalogger configuration to WiFi router.

1. Click the WiFi configuration icon, scan the WiFi datalogger bar code or enter the SN number directly. Or you can enter the plant, click the "device" TAB button, and then click "network" to select the SN.





2. WiFi configuration process of iOS and android is different. It is recommended to use the android WiFi configuration, will be more convenient.

#### A. For Android users

1. Connect WiFi network, enter password.

APP will automatically get the current mobile phone to connect to the Internet WiFi account, input WiFi network password to enter the configuration process. If the network is incorrect, please select switch network. You can also manually enter the network account when you switch the network account.

Note: 5G WiFi is not supported.

Tip: if you cannot connect to WiFi, try the following.

- If the signal strength of the selected network is <15%, the connection is unstable, please adjust the router's antenna position or increase the relay.
- Wireless module as the STA mode, the router's channel support range is 1 to 11.
- support WiFi STA router 802.11 b/g/n mode.
- Not support ", ""," ";"Special characters. It is suggested that the router's SSID and password use a-z, a-z, and 0-9 characters, such as do not use!@ # \$% & \*,.;'() ""?And other special characters.
- Some enterprises may limit the WIFI connection, so it is recommended closing limit function of the Qos.
- Support the normal routing encryption (WEP/WPAPSK WPA2PSK), does not support mixed multiple encryption methods.
- Open the router's DHCP function, otherwise unable to connect to router wifi.

If you have tried above solutions and still can't connect the router, please reset the router or restore the factory; If still can't use, please contact us to solve.



#### 2. Configuration

The system automatically connects the datalogger AP network and automatically starts the configuration after the connection is successful. Please make sure the datalogger is powered on and near the phone. If the connection is unsuccessful, the system will require manual connection to the datalogger AP network.

#### Tips:

- If you are unable to find the list of wireless networks (AP datalogger SN serial number), please make sure that the datalogger distance with wi-fi routers < 10 meters;
- If the above steps still can't find the AP (datalogger SN serial number), the connection or set may have problem, you may need to open the inverter back cover to check the connection module;
- Before troubleshooting, check with your inverter vendor to see if you can open the back cover of the inverter on your own. If not, please contact the inverter manufacturer customer service.

3. Wait 3-5 minutes until the configuration is successful, you can go back to the add device interface and continue to configure other devices.

If the configuration fails, the following reasons may be:

- Please click retry and carefully check the password of the router.
- The router network signal is poor, the distance between the datalogger and the router is too far. Please put the router closer to the datalogger.
- Does not meet the requirements of the datalogger to the router.

If the following situations occur, please reconfigure the network of datalogger devices:

- · Router replaced
- WiFi password changed
- Router SSID changed
- · Working environment has limited WIFI connections



#### B. For iOS users

#### 1. Connect WiFi network, enter password.

APP will automatically get the current mobile phone to connect to the Internet WiFi account, input WiFi network password to enter the configuration process. If the network is incorrect, please go to the iOS settings and select switch network. You can also manually enter the network account when you switch the network account.

Note: 5G WiFi is not supported.

#### Back SN: 2401440004 1 Connect 2 Configurate Android **≈** (i) A 🗢 🕕 ChinaNe HOME-WIF ÷ () Demand for Router? 4 = ( HYH123 If This Network Is Not The Network You Want to Configurate, Please Switch Network to Choose Again, Notice: 5G WiFi Not Supported IGEN-5G A = () . . ( IGEN-6F for Now IGEN-5G Switch Networ IGEN-HILINK A ? () witch to Matched WiFi Network Return to Ginlong Home App

#### 2. Connect the datalogger AP network.

Router WiFi network password input finished, click "ok", the system will prompt you to switch to the iPhone's network Settings screen, select AP XXXXXX terminal network, and then return to APP, datalogger can begin configuration.

Configuration success and failure status is same as android phones.



part 03 Ginlong Home Version

#### 3.1.1 Create plants

1. In the absence of login, click "1 minute to create the power station" in the center of the screen. Click "+" in the upper right corner to create the power station.





#### 2. Scan the code

APP only supports the scanning of the bar code/QR code of dataloggers. If there is no datalogger, you can click the "no device" and jump to the next step: input plant information.

#### 3. Input plant information

The system automatically locates the location of the station via the mobile phone GPS. If you are not in the site, you can also click "map" to select on the map.





Enter the name of the station and the owner's contact number

The name of the station is suggested to use your name, and the contact number is recommended to use your mobile phone number so as to have the installer operation in the later period.

ैंग हैं।	10:52	VP 69% 💷
Back	Confirm Plant Info	Complete
Name Yo	our Plant!(no more than 5	50)
Contact(	for EPC to contact you)	

#### 2.1.2 WiFi Configuration

GPRS datalogger can be automatically connected to the Internet, but if it is WiFi datalogger, we need make datalogger configured to the router connected to the Internet.

1. Enter the plant, click the "device" TAB button, and then click "network" to select the SN.

3131 8	10:53	ئ¶ 69% <b>□</b>	301 SU 😒	
+	中大诺卡 오	Ω	Cancel	
Ch. Suprise 2	21-45		SN: 40432377	74
25°C Sunsul 1	0:19			
	AMA			
	Updated:1Minute Ago	<u>A MARENA REAL</u>		
Int	ro Summary	Device		
Inverter	Inverter TCL010KN169C6008	Current Power 6.72kW		
Logger			7	
+Device				
Connect				
	•			

#### 2. WiFi Configuration

#### A. For Android users

1. Connect WiFi network, enter password.

APP will automatically get the current mobile phone to connect to the Internet WiFi account, input WiFi network password to enter the configuration process. If the network is incorrect, please select switch network. You can also manually enter the network account when you switch the network account.

Note: 5G WiFi is not supported.

Tip: if you cannot connect to WiFi, try the following.

- If the signal strength of the selected network is <15%, the connection is unstable, please adjust the router's antenna position or increase the relay.
- Wireless module as the STA mode, the router's channel support range is 1 to 11.
- support WiFi STA router 802.11 b/g/n mode.
- Not support ", ""," ";"Special characters. It is suggested that the router's SSID and password use a-z, a-z, and 0-9 characters, such as do not use!@ # \$% & \*,.;'() ""?And other special characters.
- Some enterprises may limit the WIFI connection, so it is recommended closing limit function of the Qos.
- Support the normal routing encryption (WEP/WPAPSK WPA2PSK), does not support mixed multiple encryption methods.
- Open the router's DHCP function, otherwise unable to connect to router wifi.

If you have tried above solutions and still can't connect the router, please reset the router or restore the factory; If still can't use, please contact us to solve.



	10	:27	&P 73%
Back	SN:409	382067	
1 Enter W	/iFi Password	0	Configuration Connection
	7	$\sim$	
	لے ا		
	Demand f	or Router?	
If This Netw Switch Ne	ork is not The C work to Choose Supp	ne You War a Again, Wai orted	it to Configurate n: 5G WiFi Not
Enter WiFi :	SSID	s	witch Network
TEOT NETO	EAR-5G		
IEST-NEIG			
IGEN-5G			
IGEN-5G	IK		
IGEN-5G IGEN-HILIN R&D	IK		

#### 2. Configuration

The system automatically connects the datalogger AP network and automatically starts the configuration after the connection is successful. Please make sure the datalogger is energized and near the phone. If the connection is unsuccessful, the system will require manual connection to the datalogger AP network.

#### Tips:

- If you are unable to find the list of wireless networks (AP datalogger SN serial number), please make sure that the datalogger distance with wi-fi routers < 10 meters;
- If the above steps still can't find the AP (datalogger SN serial number), the connection or set may appear problem, need to open the inverter back cover to check the connection module;
- Before troubleshooting, check with your inverter vendor to see if you can open the back cover of the inverter on your own. If not, please contact the inverter manufacturer customer service.

3. Wait 3-5 minutes until the configuration is successful, you can go back to the add device interface and continue to configure other devices.

If the configuration fails, the following reasons may be:

- Please click retry and carefully check the password of the router.
- The router network signal is poor, the distance between the datalogger and the router is too far. Please put the router closer to the datalogger.
- Does not meet the requirements of the datalogger to the router.

If the following situations occur, please reconfigure the network of datalogger devices:

- Router replaced
- WiFi password changed
- Router SSID changed
- · Working environment has limited WIFI connections



#### B. For iOS users

1. Connect WiFi network, enter password.

APP will automatically get the current mobile phone to connect to the Internet WiFi account, input WiFi network password to enter the configuration process. If the network is incorrect, please go to the iOS settings and select switch network. You can also manually enter the network account when you switch the network account. Note: 5G WiFi is not supported.

#### 2. Connect the datalogger AP network.

Router WiFi network password input finished, click "ok", the system will prompt you to switch to the iPhone's network Settings screen, select AP XXXXXX terminal network, and then return to APP, datalogger can begin configuration.

Configuration success and failure status is same as android phones.





#### 3.3.2 Edit plant association information.

plant association information means the relation between the editing power station and the merchant.

1. How to connect the plant to the merchant?

The plant created by the owner in the Ginlong home ver. can be connected to the installer. Click the "plant information" and select the installer. Then search the name of the installer and confirm to connect the plant.

2. How to disconnect the plant to the merchant

Owners created by power stations can cancel their association with the merchant. Click on the installer / distributors, select merchants from the list, and click the button "cancel power plant related to the installer" can be cancelled.

